

Verlegehinweise Premium Combi PLUS 2,2 mm

Premium Combi PLUS ist eine hochwertige, feuchtigkeitsunempfindliche PE- Schaumunterlage mit integrierter Dampfbremse und selbstklebendem Überlappungsstreifen.

Premium Combi PLUS ist geeignet für die schwimmende Verlegung von Fertigparkett und Laminat in stark frequentierten Räumen.

Vorbereitung: Der Untergrund muss bei der Verlegung entsprechend der VOB DIN 18 365 sauber, trocken und rissfrei sein. Die Ebenheit des Untergrundes soll mindestens den Anforderungen der DIN 18 202 (Ebenheitstoleranzen im Hochbau, Tabelle 3, Zeile 3) entsprechen.

Raumklima: Die Unterlage kann bei einer Raumtemperatur ab ca. 15°C und einer relativen Luftfeuchte von ca. 65% verlegt werden.

Verlegung: Diese Unterlage sollte vor allem auf mineralischen Untergründen verwendet werden. Eine zusätzliche Dampfbremsfolie ist nicht notwendig. Unterlage auslegen und auf Stoß ansetzen; dabei die Schaumseite nach unten und die Folie nach oben verlegen.

Schutzstreifen der Überlappung abziehen und auf der zuvor verlegten Bahn verkleben. Für die Verlegung des Oberbodenbelags bitte die Vorgaben des Herstellers beachten.

Hinweis: Nicht im Freien lagern, vor Sonneneinstrahlung schützen.

Layng instructions Premium Combi PLUS 2.2 mm

Premium Combi PLUS is a high-quality, moisture-resistant PE foam underlay with integrated damp barrier and self-adhesive overlap strip.

Premium Combi PLUS is suitable for the floating installation of parquet and laminate flooring in high traffic areas.

Preparation: for the installation, the substrate must be clean, dry and free of cracks in accordance with VOB DIN 18 365. The flatness of the substrate must at least meet the requirements of DIN 18 202 (flatness tolerances in building construction, Table 3, Line 3).

Indoor climate: The underlay can be installed at a room temperature of about 15°C and a relative air humidity of about 65%.

Installation: this underlay should be primarily used on mineral substrates. Additional damp barrier foil is not necessary. Lay the underlay on the floor and lay the next strip end-to-end; the foam side has to be laid face down and the foil side up.

Remove the protective strip from the overlap and paste it onto strip that has just been laid. When laying the top floor covering, please follow the manufacturer's instructions for use.

Note: Do not store outdoors; protect against direct sunlight.