

## Verlegehinweise Naturdämmplatten 4 mm

**Naturdämmplatten** sind Unterlagen aus natürlichen Holzfasern aus nachhaltiger Forstwirtschaft. Sie eignen sich für die schwimmende Verlegung von Laminat und Fertigparkett sowie Linoleum, Teppichboden und PVC-Bodenbelägen in normal frequentierten Räumen. Eine Verklebung des Bodenbelags auf den Naturdämmplatten können wir nicht empfehlen.

**Vorbereitung:** Der Untergrund muss bei der Verlegung entsprechend der VOB DIN 18 365 sauber, trocken und rissfrei sein. Die Ebenheit des Untergrundes soll mindestens den Anforderungen der DIN 18 202 (Ebenheitstoleranzen im Hochbau, Tabelle 3, Zeile 3) entsprechen.

**Raumklima:** Die Unterlage kann bei einer Raumtemperatur ab ca. 15°C und einer relativen Luftfeuchte von ca. 65% verlegt werden.

Die Unterlage sollte mindestens 24 Stunden bei 18°C im zu verlegenden Raum akklimatisiert werden.

**Verlegung:** Naturdämmplatten können auf allen Untergründen eingesetzt werden. Auf mineralischen Untergründen ist eine zusätzliche Dampfbremsfolie (PE-Dampfbremse AquaStop) erforderlich. Die Platten werden grundsätzlich auf der Folie verlegt. Die Verlegung der Platten erfolgt lose im Verbund mit Versatz um eine halbe Breite. Zu Wänden und Durchführungen ist ein Randabstand von 10 mm einzuhalten. Stoßkanten mit Alu-Dichtband abkleben.

**Achtung:** Bei der Verlegung darf das Material nicht begangen werden. Zur Vermeidung von punktuellen Belastungen Planken auslegen. Für die Verlegung des Oberbodenbelags bitte die Vorgaben des Herstellers beachten.

**Hinweis:** Nicht im Freien lagern, vor Sonneneinstrahlung schützen.

## Laying instructions Natural insulating boards 4 mm

**Natural insulating boards** are underlays made of natural wood fibres from sustainable forestry. They are suitable for the floating installation of laminate and parquet as well as linoleum, fitted carpets and PVC floor coverings in normal traffic areas. We do not recommend bonding the floor covering on the natural insulation plates.

**Preparation:** for the installation, the substrate must be clean, dry and free of cracks in accordance with VOB DIN 18 365. The flatness of the substrate must at least meet the requirements of DIN 18 202 (flatness tolerances in building construction, Table 3, Line 3).

**Indoor climate:** The underlay can be installed at a room temperature of about 15°C and a relative air humidity of about 65%.

The underlay should be placed for acclimatisation in the installation area for at least 24 hours at 18°C.

**Installation:** Natural insulating boards can be used on all substrates. On mineral substrates, additional damp barrier foil (PE damp barrier AquaStop) should be used. The boards are always placed onto the foil. The sheets are installed loosely and offset by half the width. A distance of 10 mm must be kept from the walls and ducts. Mask edges using aluminium sealing tape.

**Caution:** You must not walk on the material during the installation. Lay planks to avoid any point loads. When laying the top floor covering, please follow the manufacturer's instructions for use.

**Note:** Do not store outdoors; protect against direct sunlight.